

Precolor Easy

Get creative, stay natural, love colours

Precolor Easy is a pre-colour stain used in combination with Oil Plus 2C to create special effects and contrasts (e.g., increase colour intensity, cerusing, ebonizing, whitewash, etc...). Enjoy unlimited creative possibilities thanks to the option to apply one of our 14 colours of Precolor Easy with one of our 55 colours in Oil Plus 2C.

PRODUCT INFORMATION

› Specific characteristics

- Natural look
- Water-based pre-treatment
- 14 unique colours
- Ready to use
- Unlimited combinations possible (All colours in this product may be intermixed)
- Can be applied to almost all wood types and wood species (solid wood, veneer, mdf, etc.)
- Can be applied to most interior wood surfaces
- Environmentally friendly: 0% VOC

› Technical characteristics

- Physical state: liquid
- Flash point: > 140°F (60°C)
- Density: 1,01 kg/L
- VOC content: 0 g/L
- Solubility in water: 100%



Drying time	± 12h The exact drying time depends on the surface, relative humidity, temperature and ventilation.
Application information	All vertical and horizontal wood surfaces indoors
Consumption	Approximately* 150-200 ft ² /liter 15-20 ft ² /100 ml
Working temperature range	60-80 degrees F (15-25°C)
Relative humidity application range	35-60% RH
Wood Moisture Content (MC)	8-12%
Storage Temperature	Min. 40 degrees F (+5°C) / Max. 85 F (+30°C)

	The product can be stored up to 12 months in dry, frost-free conditions and in its original packaging.
Remarks	This product is a pre-treatment and does not protect the wood. It has to be finished with Oil Plus 2C for protection.

* The consumption rate is merely an estimate. Actual usage depends on the wood type, sanding, and method of preparation.

> Colours on Oak



ALPACA WHITE



ANTIQUE BEIGE



CASHMERE BROWN



INTENSE BLACK



INTENSE GREY



MINT WHITE



MONSOON GREY



MYSTIC BROWN



NORDIC WHITE



PEBBLE GREY



SMOKED BROWN



URBAN GREY



VANILLA CREAM



VINTAGE BROWN

Colours shown only serve as an example. The wood selected for colour sampling must represent the wood sourced for the actual project. All wood used for sampling should follow the same sanding sequence as required for the final project.

> Packaging



Bottle 100 ml



Can 1 L

› Storage

The product can be stored for up to 12 months in dry conditions and the original packaging. Protect against freezing.

APPLICATION INFORMATION

› Instructions

> Furniture and Stairs

STEP 1. Sand the surface properly. Finish sanding with 100-150 grit, the colour intensity depends on the sanding method used.

- When refinishing, remove any residue from previous finish treatments down to bare wood (e.g., varnish, oil, wax, etc).

STEP 2. Vacuum thoroughly and eliminate residual wood dust with Cleaner (Raw Wood Cleaner). Allow the surface to dry completely (refer to the Cleaner TDS guidelines).

STEP 3. Stir the product thoroughly before use and periodically during use.

STEP 4. Apply an even wet coat of Precolor Easy with a brush or applicator pad. Next, work the applied product into the wood using a Rubio Monocoat Scrubby pad using a forceful circular motion. As soon the surface starts to show signs of drying, immediately wipe the treated surface with a slightly water-dampened rag in a circular motion and feather out in the direction of the wood grain to even out the application.

- For smaller objects and corners, cut applicator/Scrubby pad(s) to size.

STEP 5. Allow the surface to dry for ± 12 hours. Total dry time depends on the wood's absorbency, relative humidity, surface and air temperature, and ventilation.

STEP 6. After drying, if required, smooth the raised wood fibers lightly using a red Scrubby pad and vacuum afterward.

STEP 7. Now apply the Oil Plus 2C. Please consult the technical data sheet of the oil for a correct application. Be careful, in combination with Precolor Easy it is recommended to use only a white Scrubby/applicator pad instead of a red one when applying the oil!

> Floors

STEP 1. Sand the surface following NFWA guidelines. Finish sanding with 100-120 grit sandpaper or mesh screen. The colour intensity depends on the sanding method used.

- When refinishing a wood floor, remove any residue from previous finish treatments down to bare wood (e.g., varnish, oil, wax, etc).

STEP 2. Vacuum thoroughly and eliminate residual wood dust with Cleaner (Raw Wood Cleaner). Allow the surface to dry completely (refer to the Cleaner TDS guidelines).

STEP 3. Tape off sections about 2-3 feet wide in the lengthwise direction of the boards. You will treat each section, skip each consecutive section, and continue similarly. To visualize this process, refer to our Precolor Easy + Oil Plus 2C application video here: [How to apply Precolor Easy to flooring](#).

STEP 4. Stir the product thoroughly before use and periodically during use. Pour the amount of Precolor Easy needed into a painter's tray.

STEP 5. Apply the Precolor Easy with a Rubio Monocoat Microfiber Bristle Pad. Immediately start scrubbing in the applied product with a Rubio Monocoat Scrubby pad in a circular motion. Once you notice the scrubbed-in product starts to flash off, immediately start wiping the surface again in a circular motion using a slightly water-dampened rag. Finish wiping in the length of the boards to even out the applied product. Remove the tape along each finished section immediately. **Note it will be advantageous to work in a team. One applies the product, a second does the scrubbing, and a third performs the wiping. These 3 team members shall stay relatively close together to avoid the applied product to dry too quickly!**

STEP 6. After the treated sections have dried, tape off the untreated sections and complete the room in this "stain-skip-stain" manner following the application instructions under Step 5.

STEP 7. Allow the surface to dry for ± 12 hours. Total dry time depends on the wood's absorbency, relative humidity, surface and air temperature, and ventilation.

STEP 8. After drying, and if required, smooth the raised wood fibers lightly using a thick red buffer. Vacuum and tack with a dry microfiber dust mop.

STEP 9. Now apply the Oil Plus 2C. Consult the technical data sheet for application instructions. It is important to note when applying Oil Plus 2C over Precolor Easy to use only a white buffer pad instead of a red one when applying the oil!

NOTE:

Precolor Easy is not meant to be applied on the wood surface in a thick, painted-on like fashion. Make sure to even it out in a very thin but even application.

> Industrial application

If you want to apply this product in an industrial manner, we advise you to get in contact with our technical service team.

> Tips & tricks

- Stir the product well before and during the application process.
- When using containers from different batches, intermix them together for an even colour result.
- If an in-floor heating system is present, turn the system off 48 hours before applying Precolor Easy. Once Precolor Easy has been applied, the heating system must be turned on again.
- Do not use Precolor Easy combination with water-based finishing products.
- Challenging to apply on herringbone parquet. Please reach out to our technical team for guidance.
- Keep in mind that the wood type, grain structure and porosity of the wood can influence the end result. Therefore, it is important to make a sample first on the chosen wood species or the surface that needs treating.
- Not recommended for workbenches, countertops, bar tops, etc...
- Precolor Easy is a water-based product; therefore, water-popping is not necessary.

› Consumption

Approximately*

150-200 ft²/liter

15-20 ft²/100 ml

* The consumption rate is merely an estimate. Actual usage depends on the wood type, sanding, and method of preparation.

› Tools



› Certificates



Check the packaging and the safety data sheet for more details.

For our complete assortment of products for the protection and colouring of interior and exterior wood, please visit
www.rubimonoatusa.com & www.rubimonocoatcanada.com

Rubio[®]
MONOCOAT
MUYLLE  FACON

Muyllé Façon NV
Ambachtenstraat 58
8870 Izegem (BELGIE)

Tel. +32 (0) 51 30 80 54
Fax +32 (0) 51 30 99 78
info@muylléfaçon.be

www.rubimonocoat.com

LIABILITY: It is the user's responsibility to establish, through his own tests, whether the product is suitable for the chosen application. In no case can Muyllé Façon NV be held liable for any consequential damage. The information above may be subject to changes, which will be published in the updated versions of the technical data sheet. We cannot be held liable for poor results due to causes that are not related to the quality of the product. This technical information has been drawn up based on the currently available information and knowledge. The most recent technical data sheets can be requested or are available on the website. **Date of TDS: 21/04/2023. Check the safety information before using the product.**

