



Filling Your StopLossBags®

To fill using the Filler & Adapter Tube Set, begin by fitting the dark grey filler tube over the end of the bag's spout. It's a snug fit and allows you to attach a small funnel. For a larger funnel fit the flexible red adapter tube over the grey filler tube.

Our specially formulated StopLossBags® Collapsible Funnel allows easy one-step transfer from a quart or liter can. It stretches over the top of the can while the small end fits the StopLossBags®. It is important to blow air into the bag before attaching the funnel. This allows the full transfer of finish.

The funnel is simple to clean. Place it upside down on a folded paper towel overnight. The dried finish peels easily from the inside. Note that, thin oil finishes may need to be cleaned with solvents.